



AP00.20-U-1208VC	SERVICE SHEET for Mercedes-Benz Maintenance System (USA)	20.4.06
------------------	--	---------

MODEL 171
except AMG models

Passenger cars Model Year 2007
USA



Customer: _____

Repair order number: _____

First visit	at 1,000 - 3,000 miles	Performed	YES <input type="checkbox"/>	NO <input type="checkbox"/>
-------------	------------------------	-----------	------------------------------	-----------------------------

Tire Rotation (non staggered width wheel setup only)	Performed in accordance with the tire manufacturer's recommended intervals	Tires rotated	YES <input type="checkbox"/>	NO <input type="checkbox"/>
---	--	---------------	------------------------------	-----------------------------

Tire Inspection (staggered and non-staggered width wheel setup)	Inspect tires for damage and correct tire inflation pressure	Tires inspected	YES <input type="checkbox"/>	NO <input type="checkbox"/>
--	--	-----------------	------------------------------	-----------------------------

Current mileage reading: _____

Oil grade/viscosity: _____

Additional notes: _____




Service work to be performed as advised by service advisor:




Completion date:















Confirm work has been performed by signing below:



US Service 4 through US Service 20 apply to "Additional work" items only.
Vehicle determines need for US Service 3 (Engine oil and filter change) as well as US Service 1 or US Service 2.
Perform each service as described.

US Service 1 US Service 2	first at 13,000 mi or 1 year; after first every 26,000 mi or 2 years	first at 26,000 mi or 2 years; after first every 26,000 mi or 2 years	Not OK ↓
	Engine compartment		<input type="checkbox"/> AP00.20-P-0053V <input type="checkbox"/> AP88.40-P-8851V <input type="checkbox"/> AP54.10-U-5453A <input type="checkbox"/> AP13.22-P-1351VA <input type="checkbox"/> AP42.10-P-4210V <input type="checkbox"/> AP46.00-P-4611V <input type="checkbox"/> AP82.35-P-8210N
	Interior		<input type="checkbox"/> AP00.20-P-0042V <input type="checkbox"/> AP42.00-P-4290V <input type="checkbox"/> <input type="checkbox"/> AP54.30-P-5452C <input type="checkbox"/> AP82.30-P-8252V <input type="checkbox"/> AP91.40-P-9150V
	Wheels, brakes		<input type="checkbox"/> AP40.10-P-4050V <input type="checkbox"/> AP42.10-P-4251V <input type="checkbox"/> AP42.10-P-4251V <input type="checkbox"/> AP42.10-P-4251V

US Service 1 ↓	US Service 2 ↓	Not OK ↓
<input type="checkbox"/>	<input type="radio"/> Inspect tires for damage and splits, measure tread depth, record in mm: LF RF LR RR outside _____ center _____ inside _____	<input type="checkbox"/> AP40.10-P-4051Z
<input type="checkbox"/>	<input type="radio"/> Correct tire inflation pressure and enter in bar or psi. LF RF LR RR bar/psi: _____	<input type="checkbox"/>
	Underside of vehicle <input type="radio"/> Leakage - Major components Check for chafe marks, line routing, damaged components <i>i</i> In the event of leakage, determine cause and perform repair via separate work order <input type="radio"/> Check front axle ball joints for play, check rubber boots <input type="radio"/> Inspect condition of driveshaft flexible discs <input type="radio"/> Inspect play of tie rod and and drag link joints, inspect rubber boots	<input type="checkbox"/> AP00.20-P-0053V <input type="checkbox"/> AP33.20-P-3353V <input type="checkbox"/> AP41.10-P-4152V <input type="checkbox"/> AP46.00-P-4653V
	Trunk <input type="checkbox"/> <input type="radio"/> Check trunk lighting	<input type="checkbox"/>
	Vehicle front/rear <input type="checkbox"/> <input type="radio"/> Check wiper blade condition <input type="radio"/> Check and correct headlamp setting	<input type="checkbox"/> AP82.30-P-8253G <input type="checkbox"/> AP82.10-P-8260V
Completed <input checked="" type="checkbox"/>		Not OK
	↓	↓
US Service 3	every 13,000 mi or 1 year: Engine compartment <input type="checkbox"/> Engine - oil and filter change	<input type="checkbox"/> AP18.00-P-0101VA
US Service 4	every 2 years: <input type="checkbox"/> Check bodywork for paint work damage by service advisor Underside of vehicle <input type="checkbox"/> Chassis and load-bearing body components: Check for damage and corrosion by service advisor Engine compartment <input type="checkbox"/> Replace brake fluid	<input type="checkbox"/> AP98.00-P-9850BA <input type="checkbox"/> AP00.20-P-0090BA AP42.00-P-4280V
US Service 5	every 26,000 mi or 2 years: Passenger compartment <input type="checkbox"/> Replace combination filter	AP83.00-P-8384V

Completed <input checked="" type="checkbox"/>		Not OK	
↓		↓	
US Service 6 and 7	not applicable		
US Service 8	every 52,000 mi or 4 years:		
	Engine compartment		
<input type="checkbox"/>	Replace engine air-cleaner insert		AP09.10-P-0980V
US Service 9 and 10	not applicable		
US Service 11	every 143,000 mi or 15 years:		
	Trunk		
<input type="checkbox"/>	Replace fuel filter		AP47.20-P-0780V
US Service 12 Engine 272	every 91,000 mi or 5 years:		
	Engine compartment		
<input type="checkbox"/>	Replace spark plugs		AP15.10-P-1580VA
US Service 13	every 143,000 mi or 15 years:		
	Engine compartment		
<input type="checkbox"/>	Replace coolant		AP20.00-P-2080V
US Service 14 - 19	not applicable		
US Service 20	once at 39,000 mi:		
	Underside of vehicle		
<input type="checkbox"/>	Automatic transmission - oil and filter change		AP27.00-P-2702W
Completed <input checked="" type="checkbox"/>	Perform:	Yes	Not OK
↓		↓	↓
Vehicle over 143,000 mi:			
Check if all fluid levels and changes are updated			
 AP	<input type="checkbox"/> Transmission	<input type="checkbox"/>	<input type="checkbox"/>
 AP	<input type="checkbox"/> Rear axle	<input type="checkbox"/>	<input type="checkbox"/>
Check if air, fuel, ventilation filters are updated			
 AP	<input type="checkbox"/> Engine air filter	<input type="checkbox"/>	<input type="checkbox"/>
 AP	<input type="checkbox"/> Fuel filter	<input type="checkbox"/>	<input type="checkbox"/>
 AP	<input type="checkbox"/> Combination filter	<input type="checkbox"/>	<input type="checkbox"/>
Check integrity of engine, mechanical components			
 AP	<input type="checkbox"/> Perform compression test (hot and cold) Refer to BE01.00-Z-9999AZ	<input type="checkbox"/>	<input type="checkbox"/>
 AP	<input type="checkbox"/> Perform leak down test (hot and cold)	<input type="checkbox"/>	<input type="checkbox"/> AP00.20-P-0053V
 AP	<input type="checkbox"/> Check spark plugs	<input type="checkbox"/>	<input type="checkbox"/>
 AP	<input type="checkbox"/> Exhaust system hangers and leaks	<input type="checkbox"/>	<input type="checkbox"/>
Check damaged / worn drivetrain parts			
 AP	<input type="checkbox"/> Front wheel bearing play	<input type="checkbox"/>	<input type="checkbox"/>
 AP	<input type="checkbox"/> Rear wheel bearing play	<input type="checkbox"/>	<input type="checkbox"/>
 AP	<input type="checkbox"/> Axles joint play	<input type="checkbox"/>	<input type="checkbox"/>
 AP	<input type="checkbox"/> Driveshaft flexible discs	<input type="checkbox"/>	<input type="checkbox"/>
 AP	<input type="checkbox"/> Tie rod and drag link joints	<input type="checkbox"/>	<input type="checkbox"/>