

AP00.20-U-0001G SERVICE SHEET FOR Flexible Service System (FSS) 25.9.97

MODEL 208 as of M.Y. 1998

## Passenger Cars MY 1998 to MY 2001

System is also known as "Active Service System (ASSYST)" in the Workshop Information System (WIS)

## Model 208



Cust	omer:		Repair order number:		
Confirm work has been performed by signing below		Initial Service Or	Type of service last	t performed	
Technician:			В	A	
	Determine need for type of serv	rice:	<b>↓</b>	<b>↓</b>	
	Please define type of service to be per	formed here!	,	Please note:	
	Current	odometer reading:		An A-Service must always be	
	B-Service last performed  (Enter 0 if this is a vehicle's intial			followed by a B-Service	
	Difference	in mi/km:			
		Difference < 14,000 mi 22,000 km  A-Service	Difference ≥ 14,000 mi 22 000 km	e .	
If the di records) If the di dealer r	g need for A-Service or B-Service: stance driven since the last "B-Ser ), an "A-Service" should be perfor stance driven since the last "B-Ser ecords), a "B-Service" should be p	med. vice" is <b>greater</b> (≥) than 14,0 erformed.			
Special	flat rates apply to the procedures	identified with 🗯 AP			
Determine	e "Additional work" needed,	if any:			

(check if applicable)

at approx. every:

i See last page for "Additional work".

30,000 mi / 48,000 km

60,000 mi / 96,000 km

60,000 mi / 96,000 km

or 4 years

or 4 years

or 5 years

2 years

3 years

Spark plugs

every:

completed	I 🗵	A-Service	7	O B-Service	Not O.K.	
		Brake test on dynamometer or test drive. Check parking brake and run in according to specifications (on vehicles with 4MATIC, ASR, ETS, ESP observe instructions in Maintenance Manual!). Enter brake values in N:	.*	<b>⋄</b>		AP42.00-P-4290BA
		front rear Parking brake				
		left				
		right				
0		Vehicle passenger compartment				
		Function check		_		
		Horn, headlamp flasher, hazard flas- hers, turn signals	$\boxtimes$	$\otimes$	. 🗆	
		Warning/indicator lamps, illumination and interior lighting	X	$\otimes$		
		Exterior lighting incl. headlamp	$\boxtimes$	$\otimes$		
		Windshield wipers, windshield washer system	X	$\otimes$		AP82.35-P-8252BA
		Headlamp cleaning system	X	$\otimes$		AP82.15-P-8252BA
		Check seat belts for damage and proper function	X	$\otimes$		AP91.40-P-9150Z
		Reset FSS counter in instrument cluster	$\boxtimes$	$\otimes$		
		Replace dust filter	$\boxtimes$	$\otimes$		AP83.00-P-8381A
	,	Wheels, brakes				
		Remove and reinstall wheels, rotate if necessary, does not apply for vehicles with different tire sizes front/rear		⊗		AP40.10-P-4050Z
		Check brake pads for lining thickness front/rear		$\otimes$		AP42.10-P-4251BA
		Check condition of brake discs front and rear		$\otimes$		AP42.10-P-4251BA
		Check thickness of brake pads by removing and reinstalling right front wheel	$\boxtimes$			AP42.10-P-4251BA
		Check condition of brake discs by removing and reinstalling right front wheel	$\boxtimes$			AP42.10-P-4251BA

		Inspect tires for damage and condition	$\boxtimes$	$\otimes$		AP40.10-P-4051Z
		Measure tread depth, enter in mm:	$\boxtimes$	$\otimes$		AP40.10-P-4051Z
		LF RF LR RR				
		outside				
		center				
		inside				
		Correct tire inflation pressure	$\boxtimes$	$\otimes$		
		·				
completed	ıΝ	A-Service	$\Box$	O B-Service	Not O.K.	
	<b>V</b>	Vehicle underbody	₩	<b>V</b>	<b>↓</b>	
		Visual check for		$\otimes$		AP00.00-P-0053BA
		Leakage - Major components				
		Chafe marks, line routing, components. In the event of leakage, determine cau-				
		se and perform repair via separate work				
	_	order.				
		Check condition of front axle ball joints		⊗		AP33.20-P-3353BA
	LJ	Check condition of steering's mechanical components		⊗		AP46.00-P-4650BA
		Engine compartment				
		Visually check  Leakage - Major components		$\otimes$		AP00.00-P-0053BA
÷		Chafe marks, line routing, components.				
		In the event of leakage, determine cau-				
		se and perform repair via separate work order.				
		Engine oil and filter change	$\boxtimes$	$\otimes$		AP18.00-P-0101AB
		Check and correct fluid level				
		Engine cooling system, anti-freeze and corrosion protection °C	X	$\otimes$		AP20.00-P-2010Z
		Brake system	$\boxtimes$	$\otimes$	П	AP42.10-P-4210Z
		Power steering	النت	⊗		AP46.00-P-4611BB
		AC refrigerant level		⊗		AP83.00-P-8312DA
	ш	In the event of leakage, determine cau-		<u> </u>		7.00.001 001207
		se and perform repair via separate work order.				
		Windshield washer	$\boxtimes$	$\otimes$		AP82.35-P-8210Z
		Check condition of poly-V-belt		$\otimes$		AP13.22-P-1351Z
		Lubricate throttle linkage, check function and condition		$\otimes$		AP30.10-P-3022ZA
		Lubricate catch, safety catch and hinges on engine hood.	X	$\otimes$		AP88.40-P-8821BA

io		Front, rear of vehicle				
		Inspect headlamp range adjustment of headlamps		$\otimes$		
		not with xenon headlamps				
		Inspect headlamp setting, adjust to correct setting		$\otimes$		AP82.10-P-8260A
		Replace windshield wiper rubber inserts		$\otimes$		AP82.30-P-8280Z
completed	↓   	A-Service	$_{\downarrow}^{\square}$	○ B-Service	Not O.K.	
		Trunk				
		•				
		Check				
		If so equipped:	X	$\otimes$		AP54.10-P-5410A
		Battery, wet cell Check acid level, replenish				
		Check acid level, replenish				
		Additionally, check battery condition using "Midtronics MCR 717" Tester	$\boxtimes$	$\otimes$		SI54.10-P-0003A
		Mar and made	□	$\otimes$		CIE 4 40 D 0003A
	Ш	If so equipped: Battery, AGM/VRLA with black housing Check battery condition using "Midtronics MCR 717" Tester	$\boxtimes$	⊗	Ц	SI54.10-P-0003A
		Correct tire inflation pressure in spare tire	$\boxtimes$	×		
		correct the initiation pressure in spare the				
		Additional Work	,			
complete	d ⊠	Perform:	yes		Not O.K.	
	<b>→</b>		<b>↓</b>		1	
·		At approx. every 30,000 mi/48,000 km or 4 years:				
₩AP		Check condition of drive shaft flex discs				AP41.10-P-4152Z
<b>⊯</b> AP		Retighten lock bolts of steering. Observe				AP46.20-P-4671BA
		torque.			•	
		·				

⊯AP	At approx. every 60,000 mi/96,000 km or 5 years: Replace fuel filter (as of M.Y. 2000) Engine 112, 113	AP47.20-P-0780DC
,	At approx. every 60,000 mi/96,000 km or 4 years:	
₩AP	Replace fuel filter (up to M.Y. 1999) Engine 112, 113	AP47.20-P-0780DC
₩ AP	Replace air cleaner filter element	
	Every 2 years	
₩AP	Replace brake fluid	AP42.00-P-4280BA
<b>₽</b> AP	Check body for paint damage by Service Advisor	AP98.00-P-9850BA
<b>⊯</b> AP	Check chassis and supporting body parts for damage and corrosion by Service Advisor	AP00.00-P-0090BA
	Every 3 years	
<b>⊯</b> AP	Replace coolant	AP20.00-P-2080A
F AP	Sliding/pop-up roof: clean and grease sli- ding rails and sliders	AP77.20-P-7730BA
	Replace spark plugs	
<b>₩</b> AP	At approx. every 100,000 mi/160,000 km or 4 years: (up to M.Y. 1999) Engine 112, 113	AP15.10-P-1580A
₽AP	At approx. every 100,000 mi/160,000 km or 5 years: (as of M.Y. 2000) Engine 112, 113	AP15.10-P-1580A