

AP00.20-U-0001M

SERVICE SHEET for Flexible Service System (FSS)

04.04.02

MODEL 209

Passenger Cars Model Year 2004

USA/CANADA:

System is also known as "Active Service System (ASSYST)" in the Workshop Information System (WIS)

Model 209



| Cust | omer: | | Repair order | number: | | |
|--|---|---|--------------|--|-------------|--|
| Confirm wor performed b | k has been y signing below | | | of service last | | |
| Technician: | | _ | \ | Į | Ţ | |
| | | Determine need for service: | | у В [| A | |
| | Please define type of service to be p | | | | | |
| | Current | odometer reading: | | | | |
| | B-Service last performed (Enter 0 if B-Service is performed for | | | | | |
| | Difference | in mi/km: | | | | |
| | | Difference < 14,000 mi 22,000 km A-Service | Difference | V ≥ 14,000 mi 22 000 km B-Service | | |
| work" needed, if any: (check if applicable) 60,000 | | 00 mi/80,000 km or 4 years | | every: | 2 years | |
| | | 00 mi/96,000 km or 4 years | | | 3 years | |
| | | 00 mi/96,000 km or 5 years | | | Spark plugs | |
| | 150,000 | mi/250,000km or 15 years | | | | |
| Determ If the d records If the d | s), an "A-Service" should be per | Service" is <mark>less (<) than 14,000 n</mark> formed. Service" is greater (≥) than 14,0 | | | | |

Additional flat rates apply for procedures marked with $\begin{tabular}{l} \blacktriangleright \begin{tabular}{l} AP \end{tabular}$.

| completed | J | A-Service | 1 | ○ B-Service | Not O.K. | |
|-----------|---------|--|---------------------------|-------------|---------------|------------------|
| | • | Vehicle passenger compartment | • | • | • | |
| | | Function check | | | | |
| | П | Warning/indicator lamps, illumination and | ☑ | \otimes | | |
| | ш | interior lighting | × | | Ц | |
| | | Windshield wiper, windshield washer system | \boxtimes | \otimes | | AP82.35-P-8252BA |
| | | Headlamp cleaning system | \boxtimes | \otimes | | AP82.15-P-8252BA |
| | | Check seat belts for damage and proper function | | \otimes | | AP91.40-P-9150Z |
| | | Reset FSS counter in instrument cluster | \boxtimes | \otimes | | |
| | | Wheels, brakes | | | | |
| тт | | Check front brake pads for lining thickness (remove 1 front wheel at "A" service) | \boxtimes | | | AP42.10-P-4251BA |
| | | Check brake pad thickness (front and rear) | | \otimes | | AP42.10-P-4251BA |
| | | Check condition of brake discs front and rear | | \otimes | | AP42.10-P-4251BA |
| | | Inspect tires for damage and condition | \times | \otimes | | AP40.10-P-4051Z |
| | | Measure tread depth, enter in mm: | | \otimes | | AP40.10-P-4051Z |
| | | LF RF LR RR outside center inside Correct tire inflation pressure | × | \otimes | | |
| | | Vehicle underbody | | | | |
| completed | I⊠ ↓ | A-Service | $_{\downarrow}^{\square}$ | ○ B-Service | Not O.K. ↓ | |
| | | Visual check for Leakage - Major components Chafe marks, line routing, components. In the event of leakage, determine cause and perform repair via separate work order. | | ⊗ | | AP00.20-P-0053BA |
| | | Check condition of front axle ball joints and rubber boots | | \otimes | | AP33.20-P-3353BA |
| | | Check condition of steering's mechanical components and rubber boots | | \otimes | | AP46.00-P-4653BA |
| | | | | | | |

| | | Engine compartment | | | | |
|-------------|-----|--|-------------|-----------|---------------|-----------------------------------|
| | | Visually check Leakage - Major components Chafe marks, line routing, components. In the event of leakage, determine cause and perform repair via separate work order. | | \otimes | | AP00.20-P-0053BA |
| | | Engine oil and filter change | \boxtimes | \otimes | | |
| | | Engine 112 | | | П | AP18.00-P-0101AE |
| | | Engine 113 Check and correct fluid level | | | | AP18.00-P-0101AF |
| | П | Brake system | \boxtimes | \otimes | П | AP42.10-P-4210Z |
| | | Battery Check condition of battery, using "Midtronics MCR 717" Tester | × | \otimes | | AP54.10-U-5453A |
| | | Power steering | | \otimes | | AP46.00-P-4611BB |
| | | Check condition of poly-V-belt | | \otimes | | AP13.22-P-1351Z |
| | | Windshield washer, as necessary | \times | \otimes | | AP82.35-P-8210Z |
| | | Lubricate throttle linkage, check function and condition - Not with Engine 113 | | \otimes | | AP30.10-P-3022ZA |
| | | Check catch, safety catch and hinges on engine hood for proper operation. Replace components with even the slightest malfunction. | \boxtimes | \otimes | | AP88.40-P-8821BA |
| | | | | | | |
| | | Trunk | | | | |
| | | Trunk Correct tire inflation pressure in spare tire. | ⊠ | 8 | | |
| | | | X | ⊗ | | |
| complete | | Correct tire inflation pressure in spare tire. | yes ↓ | ⊗ | □ Not O.K. | |
| complete | | Correct tire inflation pressure in spare tire. Additional Work | | ⊗ | | |
| complete | | Correct tire inflation pressure in spare tire. Additional Work Perform: At approx. every 50,000 mi/80,000 km | | ⊗ | | AP41.10-P-4152Z |
| | | Correct tire inflation pressure in spare tire. Additional Work Perform: At approx. every 50,000 mi/80,000 km or 4 years: | yes ↓ | 8 | Not O.K. ↓ | AP41.10-P-4152Z |
| | | Correct tire inflation pressure in spare tire. Additional Work Perform: At approx. every 50,000 mi/80,000 km or 4 years: Check condition of drive shaft flex discs At approx. every 60,000 mi/96,000 km | yes ↓ | ⊗ | Not O.K. ↓ | AP41.10-P-4152Z |
| ₩AP | | Correct tire inflation pressure in spare tire. Additional Work Perform: At approx. every 50,000 mi/80,000 km or 4 years: Check condition of drive shaft flex discs At approx. every 60,000 mi/96,000 km or 4 years: | yes ↓ | ⊗ | Not O.K. ↓ | AP41.10-P-4152Z |
| ₩AP | | Correct tire inflation pressure in spare tire. Additional Work Perform: At approx. every 50,000 mi/80,000 km or 4 years: Check condition of drive shaft flex discs At approx. every 60,000 mi/96,000 km or 4 years: Replace air cleaner filter element At approx. every 60,000 mi/96,000 km | yes ↓ | ⊗ | Not O.K. ↓ | AP41.10-P-4152Z AP47.20-P-0780DC |
| ⊯ AP | d ⊠ | Additional Work Perform: At approx. every 50,000 mi/80,000 km or 4 years: Check condition of drive shaft flex discs At approx. every 60,000 mi/96,000 km or 4 years: Replace air cleaner filter element At approx. every 60,000 mi/96,000 km or 5 years: | yes ↓ | ⊗ | Not O.K. □ | |

| | Every 2 years | | |
|-------------|---|--|------------------|
| | Replace dust filter | | AP83.00-P-8381A |
| ₽AP | Replace brake fluid | | AP42.00-P-4280BA |
| ₩AP | Check body for paint damage by Service Advisor | | AP98.00-P-9850BA |
| ⊯ AP | Check chassis and supporting body parts for damage and corrosion by Service Advisor | | AP00.20-P-0090BA |
| | Every 5 years | | |
| ₩AP | Sliding/pop-up roof: clean sliding rails and sliders | | AP77.20-P-7731A |
| | At approx. every 150,000 mi/250,000 km or 15 years | | |
| ⊯ AP | Replace coolant | | AP20.00-P-2080A |
| | Replace spark plugs | | |
| ₩ AP | At approx. every 100,000 mi/160,000 km or 5 years: Engine 113 | | AP15.10-P-1580A |