

AP00.20-U-0001H SERVICE SHEET for Flexible Service System (FSS)

25.9.97

MODEL 210

Passenger Cars Model Year 2002

USA/CANADA:

System is also known as "Active Service System (ASSYST)" in the Workshop Information System (WIS)

Model 210



Cus	tomer:		Repair order number:
Confirm work	k has been V signing below		Type of service last performed On new vehicles start with B
Technician:		_	В
		Determine need for service:	T
	Please define type of service to be	performed here:	
	Current	odometer reading:	
	B-Service last performed (Enter 0 if B-Service is performed for		
	Difference	in mi/km:	
		Difference < 14,000 mi 22,000 km	Difference ≥ 14,000 mi 22 000 km
		A-Service	B-Service
Determin	e "Additional work" nee	ded, if any:	
(check if a	, p	0 mi/72,000 km	
at approx.		0 mi/80,000 km	every: 2 years
	60,00 or 5 y	0 mi/96,000 km ears	Spark plugs
Determing If the discrete of t	an "A-Service" should be per	Service" is <mark>less (<)</mark> than 14,000 formed. Service" is greate r (≥) than 14,	miles/22 000 km (as determined from Service Booklet or dealer 000 miles/22 000 km (as determined from Service Booklet or

Additional flat rates apply for procedures marked with ${\begin{subarray}{c} \blacktriangleright \begin{subarray}{c} AP \end{subarray}}$.

completed [X	A-Service	P.	B-Service	Not O.K.	
,	↓		1	↓	<u> </u>	
		Brake test on dynamometer or test drive. Check parking brake and run in according to specifications (observe instructions in Maintenance Manual for vehicles with 4ETS, ASR, ESP!). Enter brake values in N:		⊗		AP42.00-P-4290BA
		front rear Parking brake				
		left				
		right				
		Vehicle passenger compartment				
		Function check				
[Check Tele Aid by pressing SOS button to make test call to Response Center	X	\otimes		
		Horn, headlamp flasher, hazard flas- hers, turn signals	\boxtimes	\otimes		
		Warning/indicator lamps, illumination and interior lighting	\boxtimes	\otimes	. 🗆	
		Exterior lighting incl. headlamps	\boxtimes	\otimes		
		Windshield wiper, rear window wiper, windshield/rear window washer system	\boxtimes	\otimes		AP82.35-P-8252BA
		Headlamp cleaning system	\boxtimes	\otimes		
. [Check seat belts for damage and proper function		\otimes		AP91.40-P-9150Z
		Reset FSS counter in instrument cluster	\boxtimes	\otimes		
		Replace dust filter		\otimes		AP83.00-P-8381S
		Check				
		If so equipped: Battery, wet cell Check acid level, replenish	X	\otimes		AP54.10-P-5410A
[Additionally check battery condition, using "Midtronics MCR 717" Tester	×	\otimes		SI54.10-P-0003A
		If so equipped: Battery, AGM/VRLA, with black housing Check battery condition using "Midtronics MCR 717" Tester	X	⊗		SI54.10-P-0003A
		Wheels, brakes		and the second s		
[Remove and reinstall wheels, rotate if necessary, does not apply for vehicles with different tire sizes front/rear		\otimes		AP40.10-P-4050Z
		Check brake pads for lining thickness front/rear (remove 1 front wheel at "A" service)		\otimes		AP42.10-P-4251BA
		Check condition of brake discs front and rear		\otimes		AP42.10-P-4251BA

		Inspect tires for damage and condition	X	\otimes		AP40.10-P-4051Z
		Measure tread depth, enter in mm:		\otimes		AP40.10-P-4051Z
		LF RF LR RR				
		outside				
		center				
		inside				
		Correct tire inflation pressure	×	8		
		Vehicle under body				
completed	I 🗵	A-Service		O B-Service	Not O.K.	
	∀	Visual check for	Ψ	∨ ⊗	∀	AP00.20-P-0053BA
	Ш	Leakage - Major components Chafe marks, line routing, components. In the event of leakage, determine cause and perform repair via separate work order.				AF00.20-F-0033BA
		Check condition of front axle ball joints and rubber boots		\otimes		AP33.20-P-3353BA
		Check condition of steering's mechanical components and rubber boots		\otimes		AP46.00-P-4653F
		Engine compartment				
		Visually check Leakage - Major components Chafe marks, line routing, components. In the event of leakage, determine cause and perform repair via separate work order.		⊗		AP00.20-P-0053BA
		Engine oil and filter change Engine 112	\boxtimes	\otimes		AP18.00-P-0101AE
		Engine 113				AP18.00-P-0101AF
		Check and correct fluid level				
		Engine cooling system, anti-freeze and correction protection °C	X	\otimes		
		Engines 112, 113				AP20.00-P-2010D
		Engine 606				AP20.00-P-2010Z
		Level control (wagon only)		\otimes		AP32.30-P-3211BB
		Brake system	\boxtimes	\otimes		AP42.10-P-4210Z
		Power steering		\otimes		AP46.00-P-4611BB
		Windshield washer	\boxtimes	\otimes		AP82.35-P-8210Z
		Check condition of poly-V-belt		\otimes		AP13.22-P-1351Z
		Lubricate throttle linkage, check function and condition Not with Engine 113		⊗		AP30.10-P-3022ZA
		Lubricate catch, safety catch and hinges on engine hood.	X	\otimes		AP88.40-P-8821BA

ide			Front, rear of vehicle				,
			Check headlamp aiming, adjust if necessary (refer to Operator's Manual for procedure)		\otimes		
			Replace windshield wiper rubber insert		\otimes		AP82.30-P-8280F
	completed	VX ↓	A-Service	\downarrow	○ B-Service↓	Not O.K. ↓	
			Inspect condition of wiper blade for rear window		\otimes		AP82.15-P-8252BA
			Inspect fluid level of rear window washer, correct		8		AP82.35-P-8210Z
6			Trunk				
			Correct tire inflation pressure in spare tire	X	\otimes		
			Additional Work				
	complete	↓ 	Perform:	yes		Not O.K.	
		·	At approx. every 45,000 mi/72,000 km or 4 years:	•		•	
₩AP			Replace activated charcoal filter M.Y. 1998 - 1999				AP83.00-P-8382F
			At approx. every 50,000 mi/80,000 km or 4 years:				
₩AP			Check condition of driveshaft flex discs				AP41.10-P-4152Z
			At approx. every 60,000 mi/96,000 km or 4 years:		, , , , , , , , , , , , , , , , , , ,		
₩AP			Replace fuel prefilter Diesel engine				AP47.20-P-0781AB
⊯ AP			Replace air cleaner filter element				
₩ AP			Check condition of fuel filler nozzle seal in filler neck, replace if damaged				AP47.10-P-4751A
			At approx. every 60,000 mi/96,000 km or 5 years:				
₩AP			Replace fuel filter Gasoline engines				AP47.20-P-0780DC
₩AP			Replace fuel filter Diesel engine				AP47.20-P-0780BA
₩AP			Replace activated charcoal filter As of M.Y. 2000				AP83.00-P-8382F

		Every 2 years			
⊯ AP		Replace brake fluid			AP42.00-P-4280BA
₩AP		Check body for paint damage by Service Advisor			AP98.00-P-9850BA
₩ÃΡ		Check chassis and supporting body parts for damage and corrosion by Service Advisor			AP00.20-P-0090BA
	completed ⊠	Perform:	yes	Not Q.K.	
	1		1	↓	
		Every 3 years			
₩AP		Replace coolant Gasoline engines			AP20.00-P-2080A
		Diesel engine			AP20.00-P-2080B
₽ÃΡ		Sliding/pop-up roof: clean and grease sliding rails and sliders			AP77.20-P-7730BA
	***	Replace spark plugs			
₩AP		At approx. every 100,000 mi/160,000 km or 4 years: M.Y. 1998 - 1999			AP15.10-P-1580A
₩AP		At approx. every 100,000 mi/160,000 km or 5 years: As of M.Y. 2000			AP15.10-P-1580A