




MODEL 221

except AMG models and S600

Passenger cars Model Year 2007
USA

Model 221



Customer: _____

Repair order number: _____

First visit at 1,000 - 3,000 miles

Performed YES NO

Tire Rotation
(non staggered width wheel setup only)
Performed in accordance with the tire manufacturer's recommended intervals

Tires rotated YES NO

Tire Inspection
(staggered and non-staggered width wheel setup)
Inspect tires for damage and correct tire inflation pressure

Tires inspected YES NO

Current mileage reading: _____

Oil grade/viscosity: _____

Additional notes: _____



Service work to be performed as advised by service advisor:

Completion date:

Confirm work has been performed by signing below:



US Service 4 through US Service 20 apply to "Additional work" items only.
Vehicle determines need for US Service 3 (Engine oil and filter change) as well as US Service 1 or US Service 2.
Perform each service as described.

| US Service 1 | US Service 2 | first at 13,000 mi or 1 year; after first every 26,000 mi or 2 years | first at 26,000 mi or 2 years; after first every 26,000 mi or 2 years | Not OK | | | | | | | | | | | | | | | | | | | | |
|---|-----------------------------|--|---|------------------|----|----|----|----------|-------|-------|-------|-------|--------|-------|-------|-------|-------|--------|-------|-------|-------|-------|--|--|
| ↓ | ↓ | | | ↓ | | | | | | | | | | | | | | | | | | | | |
|  | Interior | | | | | | | | | | | | | | | | | | | | | | | |
| <input type="checkbox"/> | <input type="radio"/> | Reset service indicator in instrument cluster | | AP00.20-P-0042SX | | | | | | | | | | | | | | | | | | | | |
| <input type="checkbox"/> | <input type="radio"/> | Night View Assist camera - clean windshield behind the camera cover | | AP54.30-P-5431SX | | | | | | | | | | | | | | | | | | | | |
| Function test | | | | | | | | | | | | | | | | | | | | | | | | |
| <input type="checkbox"/> | <input type="radio"/> | Check parking brake (function test only) | <input type="checkbox"/> | AP42.00-P-4292SX | | | | | | | | | | | | | | | | | | | | |
| <input type="checkbox"/> | <input type="radio"/> | Horn, warning/indicator lamps, illumination and interior lighting | <input type="checkbox"/> | | | | | | | | | | | | | | | | | | | | | |
| <input type="checkbox"/> | <input type="radio"/> | Windshield wipers, windshield washer system | <input type="checkbox"/> | AP82.30-P-8252SX | | | | | | | | | | | | | | | | | | | | |
| <input type="checkbox"/> | <input type="radio"/> | Headlamp cleaning system | <input type="checkbox"/> | | | | | | | | | | | | | | | | | | | | | |
| <input type="checkbox"/> | <input type="radio"/> | Check seat belts and buckles for signs of external damage and proper function | <input type="checkbox"/> | AP91.40-P-9150SX | | | | | | | | | | | | | | | | | | | | |
|  | Wheels, brakes | | | | | | | | | | | | | | | | | | | | | | | |
| <input type="checkbox"/> | <input type="radio"/> | Inspect tires for damage and splits, measure tread depth, enter in mm: | <input type="checkbox"/> | AP40.10-P-4051SX | | | | | | | | | | | | | | | | | | | | |
| | | <table border="0"> <tr> <td></td> <td style="text-align: center;">LF</td> <td style="text-align: center;">RF</td> <td style="text-align: center;">LR</td> <td style="text-align: center;">RR</td> </tr> <tr> <td>outside</td> <td style="text-align: center;">_____</td> <td style="text-align: center;">_____</td> <td style="text-align: center;">_____</td> <td style="text-align: center;">_____</td> </tr> <tr> <td>center</td> <td style="text-align: center;">_____</td> <td style="text-align: center;">_____</td> <td style="text-align: center;">_____</td> <td style="text-align: center;">_____</td> </tr> <tr> <td>inside</td> <td style="text-align: center;">_____</td> <td style="text-align: center;">_____</td> <td style="text-align: center;">_____</td> <td style="text-align: center;">_____</td> </tr> </table> | | LF | RF | LR | RR | outside | _____ | _____ | _____ | _____ | center | _____ | _____ | _____ | _____ | inside | _____ | _____ | _____ | _____ | | |
| | LF | RF | LR | RR | | | | | | | | | | | | | | | | | | | | |
| outside | _____ | _____ | _____ | _____ | | | | | | | | | | | | | | | | | | | | |
| center | _____ | _____ | _____ | _____ | | | | | | | | | | | | | | | | | | | | |
| inside | _____ | _____ | _____ | _____ | | | | | | | | | | | | | | | | | | | | |
| <input type="checkbox"/> | <input type="radio"/> | Remove and install wheels | | AP40.10-P-4050SX | | | | | | | | | | | | | | | | | | | | |
| <input type="checkbox"/> | <input type="radio"/> | Check front brake pads for lining thickness (remove right front wheel) | <input type="checkbox"/> | AP42.10-P-4251SX | | | | | | | | | | | | | | | | | | | | |
| <input type="checkbox"/> | <input type="radio"/> | Check front/rear brake pads for lining thickness | <input type="checkbox"/> | AP42.10-P-4251SX | | | | | | | | | | | | | | | | | | | | |
| <input type="checkbox"/> | <input type="radio"/> | Check condition/thickness of front/rear brake discs | <input type="checkbox"/> | AP42.10-P-4251SX | | | | | | | | | | | | | | | | | | | | |
| <input type="checkbox"/> | <input type="radio"/> | Correct tire inflation pressure and enter in bar or psi. | <input type="checkbox"/> | | | | | | | | | | | | | | | | | | | | | |
| | | <table border="0"> <tr> <td></td> <td style="text-align: center;">LF</td> <td style="text-align: center;">RF</td> <td style="text-align: center;">LR</td> <td style="text-align: center;">RR</td> </tr> <tr> <td>bar/psi:</td> <td style="text-align: center;">_____</td> <td style="text-align: center;">_____</td> <td style="text-align: center;">_____</td> <td style="text-align: center;">_____</td> </tr> </table> | | LF | RF | LR | RR | bar/psi: | _____ | _____ | _____ | _____ | | | | | | | | | | | | |
| | LF | RF | LR | RR | | | | | | | | | | | | | | | | | | | | |
| bar/psi: | _____ | _____ | _____ | _____ | | | | | | | | | | | | | | | | | | | | |
|  | Underside of vehicle | | | | | | | | | | | | | | | | | | | | | | | |
| <input type="checkbox"/> | <input type="radio"/> | Leakage - Major components Check for chafe marks, line routing, damaged components <input type="checkbox"/> In the event of leakage, determine cause and perform repair via separate work order | <input type="checkbox"/> | AP00.20-P-0053SX | | | | | | | | | | | | | | | | | | | | |
| <input type="checkbox"/> | <input type="radio"/> | Check front axle ball joints for play, check rubber boots | <input type="checkbox"/> | AP33.20-P-3353SX | | | | | | | | | | | | | | | | | | | | |
| <input type="checkbox"/> | <input type="radio"/> | Inspect condition of driveshaft flexible discs | <input type="checkbox"/> | AP41.10-P-4152SX | | | | | | | | | | | | | | | | | | | | |
| <input type="checkbox"/> | <input type="radio"/> | Inspect play of tie rod and drag link joints, inspect rubber boots | <input type="checkbox"/> | AP46.00-P-4653SX | | | | | | | | | | | | | | | | | | | | |

| US Service 1 ↓ | US Service 2 ↓ | | Not OK ↓ |
|---|-----------------------|--|---|
|  | | Vehicle front/rear | |
| <input type="checkbox"/> | <input type="radio"/> | Check and correct headlamp setting | <input type="checkbox"/> AP82.10-P-8260SX |
| <input type="checkbox"/> | <input type="radio"/> | Check wiper blade condition | <input type="checkbox"/> AP82.30-P-8253SX |
|  | | Trunk | |
| <input type="checkbox"/> | <input type="radio"/> | Check auxiliary battery condition using "Midtronics MCR 717" Tester. Attach "Midtronics MCR 717" Test Report print out here. | <input type="checkbox"/> AP54.10-U-5453A |
| <input type="checkbox"/> | <input type="radio"/> | Correct inflation pressure in spare tire and enter in bar or psi. bar/psi: _____ | <input type="checkbox"/> |
| <input type="checkbox"/> | <input type="radio"/> | Check trunk lighting | <input type="checkbox"/> |
|  | | Engine compartment | |
| | <input type="radio"/> | Leakage - Major components Check for chafe marks, line routing, damaged components [i] In the event of leakage, determine cause and perform repair via separate work order | <input type="checkbox"/> AP00.20-P-0053SX |
| <input type="checkbox"/> | <input type="radio"/> | Check catch, safety catch and hinges on engine hood for proper operation. | <input type="checkbox"/> AP88.40-P-8851SX |
| | <input type="radio"/> | Check condition of poly-V-belt Check fluid level, correct as required [i] If there is a loss of fluid, determine cause and perform repair via separate work order | <input type="checkbox"/> |
| <input type="checkbox"/> | <input type="radio"/> | Starter battery, check and correct fluid level; Check battery condition using "Midtronics MCR 717" Tester. Attach "Midtronics MCR 717" Test Report print out here. | <input type="checkbox"/> AP54.10-U-5453A |
| <input type="checkbox"/> | <input type="radio"/> | Brake system | <input type="checkbox"/> AP42.10-P-4210SX |
| <input type="checkbox"/> | <input type="radio"/> | Power steering | <input type="checkbox"/> AP46.00-P-4611SX |
| | <input type="radio"/> | Active Body Control (Code 487) | <input type="checkbox"/> AP32.50-P-3213SX |
| <input type="checkbox"/> | <input type="radio"/> | Windshield washer system (incl. summer/winter cleanser) | <input type="checkbox"/> AP82.35-P-8210SX |

| Additional Work | |
|--|--|
| Completed <input checked="" type="checkbox"/> | Not OK |
| ↓ | ↓ |
| US Service 3 every 13,000 mi or 1 year: Engine compartment <input type="checkbox"/> Engine - oil and filter change | <input type="checkbox"/> AP18.00-P-0101SX |
| US Service 4 every 2 years: <input type="checkbox"/> Check bodywork for paint work damage by service advisor Underside of vehicle <input type="checkbox"/> Chassis and load-bearing body components: Check for damage and corrosion by service advisor Engine compartment <input type="checkbox"/> Replace brake fluid | <input type="checkbox"/> AP98.00-P-9850SX <input type="checkbox"/> AP00.20-P-0090SX AP42.00-P-4280SX |
| US Service 5 every 26,000 mi or 2 years: Passenger compartment <input type="checkbox"/> Replace combination filter | AP83.00-P-8384SX |
| US Service 6 & 7 not applicable | |
| US Service 8 every 52,000 mi or 4 years: Engine compartment <input type="checkbox"/> Replace engine air-cleaner insert | AP09.10-P-0980SX |
| US Service 9 every 5 years: Passenger compartment <input type="checkbox"/> Tilting/sliding roof: Clean slide rail and slide block | AP77.20-P-7731SX |
| US Service 10 every 3 years: Passenger compartment <input type="checkbox"/> Panoramic sliding roof - clean and lubricate guide mechanism | AP77.20-P-7732SX |
| US Service 11 every 143,000 mi or 15 years: Passenger compartment <input type="checkbox"/> Replace fuel filter | AP47.20-P-0780SX |
| US Service 12 Engine 273 every 91,000 mi or 5 years: Engine compartment <input type="checkbox"/> Replace spark plugs | AP15.10-P-1580SX |
| US Service 13 every 143,000 mi or 15 years: Engine compartment <input type="checkbox"/> Replace coolant | AP20.00-P-2080SX |
| US Service 14 - 19 not applicable | |
| US Service 20 once at 39,000 mi: Underside of vehicle <input type="checkbox"/> Automatic transmission - oil and filter change | AP27.00-P-2702W |

| Completed <input checked="" type="checkbox"/> | Perform: | Yes | Not OK |
|--|---|--------------------------|---|
| ↓ | | ↓ | ↓ |
| | Vehicle over 143,000 mi: | | |
| | Check if all fluid levels and changes are updated | | |
|  AP | <input type="checkbox"/> Transmission | <input type="checkbox"/> | <input type="checkbox"/> |
|  AP | <input type="checkbox"/> Rear axle | <input type="checkbox"/> | <input type="checkbox"/> |
|  AP | <input type="checkbox"/> Front axle (if applicable) | <input type="checkbox"/> | <input type="checkbox"/> |
|  AP | <input type="checkbox"/> Transfer case (if applicable) | <input type="checkbox"/> | <input type="checkbox"/> |
| | Check if air, fuel, ventilation filters are updated | | |
|  AP | <input type="checkbox"/> Engine air filter | <input type="checkbox"/> | <input type="checkbox"/> |
|  AP | <input type="checkbox"/> Fuel filter | <input type="checkbox"/> | <input type="checkbox"/> |
|  AP | <input type="checkbox"/> Combination filter | <input type="checkbox"/> | <input type="checkbox"/> |
| | Check integrity of engine, mechanical components | | |
|  AP | <input type="checkbox"/> Perform compression test (hot and cold) Refer to BE01.00-Z-9999AZ | <input type="checkbox"/> | <input type="checkbox"/> |
|  AP | <input type="checkbox"/> Perform leak down test (hot and cold) | <input type="checkbox"/> | <input type="checkbox"/> AP00.20-P-0053SX |
|  AP | <input type="checkbox"/> Check spark plugs | <input type="checkbox"/> | <input type="checkbox"/> |
|  AP | <input type="checkbox"/> Exhaust system hangers and leaks | <input type="checkbox"/> | <input type="checkbox"/> |
| | Check damaged / worn drivetrain parts | | |
|  AP | <input type="checkbox"/> Front wheel bearing play | <input type="checkbox"/> | <input type="checkbox"/> |
|  AP | <input type="checkbox"/> Rear wheel bearing play | <input type="checkbox"/> | <input type="checkbox"/> |
|  AP | <input type="checkbox"/> Axle joint play | <input type="checkbox"/> | <input type="checkbox"/> |
|  AP | <input type="checkbox"/> Driveshaft flexible discs | <input type="checkbox"/> | <input type="checkbox"/> |
|  AP | <input type="checkbox"/> Tie rod and drag link joints | <input type="checkbox"/> | <input type="checkbox"/> |