

MODEL 164
except AMG and diesel models

Light Truck Model Year 2007
 USA

Model 164



Customer: _____

Repair order number: _____

First visit	at 1,000 - 3,000 miles	Performed	YES <input type="checkbox"/>	NO <input type="checkbox"/>
-------------	------------------------	-----------	------------------------------	-----------------------------

Tire Rotation	Performed in accordance with the tire manufacturer's recommended intervals	Tires rotated	YES <input type="checkbox"/>	NO <input type="checkbox"/>
---------------	--	---------------	------------------------------	-----------------------------

Tire Inspection	Inspect tires for damage and correct tire inflation pressure	Tires inspected	YES <input type="checkbox"/>	NO <input type="checkbox"/>
-----------------	--	-----------------	------------------------------	-----------------------------

Current mileage reading: _____

Oil grade/viscosity: _____

Additional notes: _____




Service work to be performed as advised by service advisor: _____




Completion date: _____

















Confirm work has been performed by signing below: _____



US Service 4 through US Service 20 apply to "Additional work" items only.
 Vehicle determines need for US Service 3 (Engine oil and filter change) as well as US Service 1 or US Service 2
 Perform service necessary as indicated in display of instrument cluster only.
 Perform each service as described.

US Service 1 ↓ US Service 2 ↓	first at 13,000 mi or 1 year; after first every 26,000 mi or 2 years first at 26,000 mi or 2 years; after first every 26,000 mi or 2 years	Not OK ↓																														
	Interior <input type="checkbox"/> <input type="radio"/> Reset service indicator in instrument cluster Function test <input type="checkbox"/> <input type="radio"/> Check battery condition using "Midtronics MCR 717" Tester. Attach Midtronics MCR 717 Test Report print out here. <input type="checkbox"/> <input type="radio"/> Check parking brake (function test only) <input type="checkbox"/> <input type="radio"/> Horn, warning/indicator lamps, illumination and interior lighting <input type="checkbox"/> <input type="radio"/> Windshield wipers, windshield washer system, headlamp cleaning system <input type="checkbox"/> <input type="radio"/> Check seat belts and buckles for signs of external damage and proper function	AP00.20-P-0042GZ <input type="checkbox"/> AP54.10-U-5453A <input type="checkbox"/> AP42.00-P-4290GZ <input type="checkbox"/> <input type="checkbox"/> AP82.30-P-8252GZ <input type="checkbox"/> AP91.40-P-9150GZ																														
	Wheels, brakes <input type="checkbox"/> <input type="radio"/> Inspect tires for damage and splits, measure tread depth, record in mm: <table style="margin-left: 40px;"> <thead> <tr> <th></th> <th>LF</th> <th>RF</th> <th>LR</th> <th>RR</th> </tr> </thead> <tbody> <tr> <td>outside</td> <td>_____</td> <td>_____</td> <td>_____</td> <td>_____</td> </tr> <tr> <td>center</td> <td>_____</td> <td>_____</td> <td>_____</td> <td>_____</td> </tr> <tr> <td>inside</td> <td>_____</td> <td>_____</td> <td>_____</td> <td>_____</td> </tr> </tbody> </table> <input type="checkbox"/> <input type="radio"/> Remove and fit wheels <input type="checkbox"/> <input type="radio"/> Check front brake pads for lining thickness, (remove right front wheel) <input type="checkbox"/> <input type="radio"/> Check front/rear brake pads for lining thickness <input type="checkbox"/> <input type="radio"/> Check condition/thickness of front/rear brake discs <input type="checkbox"/> <input type="radio"/> Correct tire inflation pressure and enter in bar or psi. <table style="margin-left: 40px;"> <thead> <tr> <th></th> <th>LF</th> <th>RF</th> <th>LR</th> <th>RR</th> </tr> </thead> <tbody> <tr> <td>bar/psi:</td> <td>_____</td> <td>_____</td> <td>_____</td> <td>_____</td> </tr> </tbody> </table>		LF	RF	LR	RR	outside	_____	_____	_____	_____	center	_____	_____	_____	_____	inside	_____	_____	_____	_____		LF	RF	LR	RR	bar/psi:	_____	_____	_____	_____	<input type="checkbox"/> AP40.10-P-4051Z <input type="checkbox"/> AP40.10-P-4050Z <input type="checkbox"/> AP42.10-P-4251GZ <input type="checkbox"/> AP42.10-P-4251GZ <input type="checkbox"/> AP42.10-P-4251GZ <input type="checkbox"/>
	LF	RF	LR	RR																												
outside	_____	_____	_____	_____																												
center	_____	_____	_____	_____																												
inside	_____	_____	_____	_____																												
	LF	RF	LR	RR																												
bar/psi:	_____	_____	_____	_____																												
	Underside of vehicle <input type="checkbox"/> <input type="radio"/> Leakage - Major components Check for chafe marks, line routing, damaged components <input type="checkbox"/> <input type="radio"/> In the event of leakage, determine cause and perform repair via separate work order <input type="checkbox"/> <input type="radio"/> Inspect condition of driveshaft flexible discs <input type="checkbox"/> <input type="radio"/> Check front axle ball joints for play, check rubber boots <input type="checkbox"/> <input type="radio"/> Check rear axle ball joints for play, check rubber boots <input type="checkbox"/> <input type="radio"/> Inspect play of tie rod and and drag link joints, inspect rubber boots	<input type="checkbox"/> AP00.20-P-0053GZ <input type="checkbox"/> <input type="checkbox"/> AP33.20-P-3353GZ <input type="checkbox"/> AP35.20-P-3555GZ <input type="checkbox"/> AP46.00-P-4653GZ																														

US Service 1 ↓	US Service 2 ↓		Not OK ↓
		Vehicle front/rear	
<input type="checkbox"/>	<input type="radio"/>	Check wiper blade condition	<input type="checkbox"/> AP82.30-P-8253G
	<input type="radio"/>	Check and correct headlamp setting	<input type="checkbox"/> AP82.10-P-8260GZ
		Trunk	
<input type="checkbox"/>	<input type="radio"/>	Correct inflation pressure in spare tire and enter in bar or psi. bar/psi: _____	<input type="checkbox"/>
		Engine compartment	
	<input type="radio"/>	Leakage - Major components Check for chafe marks, line routing, damaged components i In the event of leakage, determine cause and perform repair via separate work order	<input type="checkbox"/> AP00.20-P-0053GZ
<input type="checkbox"/>	<input type="radio"/>	Check catch, safety catch and hinges on engine hood for proper operation.	<input type="checkbox"/> AP88.40-P-8851GZ
	<input type="radio"/>	Check condition of poly-V-belt Check fluid level, correct as required i If there is a loss of fluid, determine cause and perform repair via separate work order	<input type="checkbox"/>
<input type="checkbox"/>	<input type="radio"/>	Brake system	<input type="checkbox"/> AP42.10-P-4210GZ
	<input type="radio"/>	Power steering	<input type="checkbox"/> AP46.00-P-4611GZ
<input type="checkbox"/>	<input type="radio"/>	Windshield washer system (incl. summer/winter cleanser)	AP82.35-P-8210GZ
Completed <input checked="" type="checkbox"/>		Additional Work	Not OK ↓
US Service 3	every 13,000 mi or 1 year:	Engine compartment	
<input type="checkbox"/>	Engine - oil and filter change	Engine 113:	AP18.00-P-0101GZ
		Engine 272, 273:	AP18.00-P-0101GZC
US Service 4	every 2 years:		
<input type="checkbox"/>	Check bodywork for paint work damage by service advisor		<input type="checkbox"/> AP98.00-P-9850GZ
	Underside of vehicle		
<input type="checkbox"/>	Chassis and load-bearing body components: Check for damage and corrosion by service advisor		<input type="checkbox"/> AP00.20-P-0090GZ
	Engine compartment		
<input type="checkbox"/>	Replace brake fluid		AP42.00-P-4280GZ
US Service 5	every 26,000 mi or 2 years:		
	Passenger compartment		
<input type="checkbox"/>	Replace combination filter		AP83.00-P-8384GZ
US Service 6 and 7	not applicable		

Completed <input checked="" type="checkbox"/>	↓	Not OK	↓
US Service 8	every 52,000 mi or 4 years: Engine compartment	<input type="checkbox"/> Replace engine air-cleaner insert	Engine 113: AP09.10-P-0980GZ Engine 272, 273: AP09.10-P-0980GZC
US Service 9 and 10	not applicable		
US Service 11 Engines 272, 273, 113	every 143,000 mi or 15 years: Passenger compartment	<input type="checkbox"/> Replace fuel filter	AP47.20-P-0780GZ
US Service 12	every 91,000 mi or 5 years: Engine compartment	<input type="checkbox"/> Replace spark plugs	Engine 113: AP15.10-P-1580GZ Engine 272, 273: AP15.10-P-1580GZC
US Service 13	every 143,000 mi or 15 years: Engine compartment	<input type="checkbox"/> Replace coolant	Engine 113, 273: AP20.00-P-2080GZ Engine 272: AP20.00-P-2080GZC
US Service 14 - 19	not applicable		
US Service 20	once at 39,000 mi: Underside of vehicle	<input type="checkbox"/> Automatic transmission - oil and filter change	AP27.00-P-2702W
Vehicle over 143,000 mi:			
Check if all fluid levels and changes are up-dated			
	<input type="checkbox"/> Transmission	<input type="checkbox"/>	<input type="checkbox"/>
	<input type="checkbox"/> Rear axle	<input type="checkbox"/>	<input type="checkbox"/>
	<input type="checkbox"/> Front axle	<input type="checkbox"/>	<input type="checkbox"/>
	<input type="checkbox"/> Transfer case	<input type="checkbox"/>	<input type="checkbox"/>
Check if air, fuel, ventilation filters are up-dated			
	<input type="checkbox"/> Engine air filter	<input type="checkbox"/>	<input type="checkbox"/>
	<input type="checkbox"/> Fuel filter	<input type="checkbox"/>	<input type="checkbox"/>
	<input type="checkbox"/> Combination filter	<input type="checkbox"/>	<input type="checkbox"/>
Check integrity of engine, mechanical components			
	<input type="checkbox"/> Perform compression test (hot and cold) Refer to BE01.00-Z-9999AZ	<input type="checkbox"/>	<input type="checkbox"/>
	<input type="checkbox"/> Perform leak down test (hot and cold)	<input type="checkbox"/>	<input type="checkbox"/> AP00.20-P-0053GZ
	<input type="checkbox"/> Check spark plugs	<input type="checkbox"/>	<input type="checkbox"/>
	<input type="checkbox"/> Exhaust system hangers and leaks	<input type="checkbox"/>	<input type="checkbox"/>
Check damaged / worn drivetrain parts			
	<input type="checkbox"/> Front wheel bearing play	<input type="checkbox"/>	<input type="checkbox"/>
	<input type="checkbox"/> Rear wheel bearing play	<input type="checkbox"/>	<input type="checkbox"/>
	<input type="checkbox"/> Axles joint play	<input type="checkbox"/>	<input type="checkbox"/>
	<input type="checkbox"/> Driveshaft flexible discs	<input type="checkbox"/>	<input type="checkbox"/>
	<input type="checkbox"/> Tie rod and drag link joints	<input type="checkbox"/>	<input type="checkbox"/>