

AP00.20-U-0001A

SERVICE SHEET for Flexible Service System (FSS)

30.7.97

Model 463

G-Class Model Year 2003

USA/CANADA:

System is also known as "Active Service System (ASSYST)" in the Workshop Information System (WIS)

Model 463



Customer:		Repair order number:			
Confirm work has been performed by signing below			Type of service last performed On new vehicles start with B		
Technician:		_			
		Determine need for service:	B A		
	Please define type of service to be p				
	Current	odometer reading:			
	B-Service last performed				
	(Enter 0 if B-Service is performed for				
	Difference	in mi/km:			
		Difference < 14,000 mi 22,000 km A-Service	Difference ≥ 14,000 mi 22 000 km B-Service		
Determi	ne "Additional work" need	led, if any:			
(check if a	pplicable) 60,000 m	i/96,000 km or 4 years	every: 2 years		
at approx	. every: 60,000 m	i/96,000 km or 5 years	3 years		
			Spark plugs		
Determ If the di records If the di dealer r), an "A-Service" should be perf	service" is less (<) than 14,000 formed. Service" is greater (≥) than 14 e performed.	miles/22 000 km (as determined from Service Booklet or dealer ,000 miles/22 000 km (as determined from Service Booklet or		

completed ⊠	A-Service		O B-Service	Not O.K.	
	Vehicle passenger compartment	•	•	·	
	Function check				
	Warning/indicator lamps, illumination and interior lighting	\boxtimes	\otimes		
	Windshield wipers, rear window wiper, windshield/rear window washer system, headlamp cleaning system	\boxtimes	\otimes		AP82.30-P-8252G
	Lubricate door locks, incl. rear door		\otimes		AP72.00-P-7221G
	Check seat belts for damage and proper function		\otimes		AP91.40-P-9150G
	Reset FSS counter in instrument cluster	\boxtimes	\otimes		
	Check				
	l - If so equipped: Battery, wet cell Check acid level, replenish	X	⊗		AP54.10-P-5410A
	Additionally, check battery condition using "Midtronics MCR 717" Tester	\boxtimes	\otimes		AP54.10-U-5453A
	If so equipped: Battery, AGM/VRLA, with black housing Check battery condition using "Midtronics MCR 717" tester	×	⊗		AP54.10-U-5453A
	Wheels, brakes				
' '	Check front brake pads for lining thickness (remove 1 front wheel at "A" service)	\boxtimes			AP42.10-P-4251G
	Check brake pad thickness (front and rear)		\otimes		AP42.10-P-4251G
	Check condition/thickness of brake discs front and rear		\otimes		AP42.10-P-4251G
	Check tires for damage and condition	\boxtimes	\otimes		AP40.10-P-4051G
	Measure tread depth, enter in mm:		\otimes		AP40.10-P-4051G
	LF RF LR RR outside center				
	inside				
		X	\otimes		

	Vehicle underbody				
completed 🗵	A-Service		○ B-Service	Not O.K.	
↓		\downarrow	Ţ	\downarrow	
	Visual check for: Leakage - Major components Chafe marks, line routing, damaged components. In the event of leakage, determine cause and perform repair via separate work order.		⊗		AP00.20-P-0053A
	Check condition of front axle joints and rubber bushings		\otimes		AP33.20-P-3353GH
	Check condition of rear axle rubber bushings		\otimes		AP35.20-P-3555GH
	Check condition of steering's mechanical components and rubber boots		\otimes		AP46.00-P-4653G
	Check fluid level, top up if necessary.				
	Transfer case		\otimes		AP28.00-P-2810G
	Front axle		\otimes		AP33.10-P-3310G
	Rear axle		\otimes		AP35.10-P-3510G
	If loss of fluid present, determine cause and rectify subject to separate repair order				
	Lubricate propeller shaft universal joints and collapsible sections	\boxtimes	\otimes		AP41.10-P-4121G
	Engine compartment				
	Visually check: Leakage - Major components Chafe marks, line routing, damaged components. In the event of leakage, determine cause and perform repair via separate work order.		8		AP00.20-P-0053A
	Engine oil and filter change	\boxtimes	\otimes		AP18.00-P-0101GB
	Check and correct fluid level				
	Differential lock mechanism: Engage differential locks, move vehicle short distance to engage locks, then unlock differential locks.	\boxtimes	⊗		AP29.00-P-2912G
	Brake system	\boxtimes	\otimes		AR42.10-P-0015GG
	Power steering		\otimes		AP46.00-P-4611G
	Windshield washer	\times	\otimes		AP82.35-P-8210G
	Check condition of poly-V-belt		\otimes		AP13.22-P-1351GA
	Lubricate joints on throttle control, check operation and condition		\otimes		AP30.10-P-3022G

		Check catch, safety catch and hinges on engine hood for proper operation. Replace components with even slightest malfunction.	\boxtimes	8		AP88.40-P-8821G
		Additional Work				
	completed 🗵	Perform:	yes		Not O.K.	
	1	Every 2 years:	↓		\downarrow	
		Replace dust filter				AP83.00-P-8381GA
₩AP		Replace brake fluid				AP42.50-P-4280G
₽ÃΡ	. 🗆	Check body for paint damage by Service Advisor				AP98.00-P-9850G
		Bolts attaching steering (check/tighten)				AP46.20-P-4671G
₽¥AP		Joint housing of AWD front axle - inspect grease packing and correct				AP33.10-P-3321G
		Every 3 years:			7.77	
F≆AP		Replace coolant				AP20.00-P-2080GA
		Every 5 years:				
₩AΡ		Sliding/pop-up roof: clean and grease sliding rails and sliders				AP77.20-P-7730G
₩AP		At approx. every 60,000 mi/96,000 km or 4 years				
₩AP		Replace air cleaner filter element				
₩AP		At approx. every 60,000 mi/96,000 km or 5 years				
		Replace fuel filter				AP47.20-P-0780GA
		Oil change in front axle				AP33.00-P-3301G
		Oil change in rear axle				AP35.00-P-3501G
		Oil change in transfer case				AP28.00-P-2801G
		Replace spark plugs				
₩AP		At approx. every 100,000 mi/160,000 km or 5 years				AP15.10-P-1580GA