

AP00.20-U-0001A

SERVICE SHEET for Flexible Service System (FSS)

30.7.97

MODEL 163

Light Truck Model Year 2003

USA/CANADA:

System is also known as "Active Service System (ASSYST)" in the Workshop Information System (WIS)

Model 163



Confirm wo	rk has been		
performed l	by signing below		Type of service last performed
Technician:			On new vehicles start with B
ecimician.			<u> </u>
		Determine need for service:	B A
	Please define type of service to be pe	rformed here:	
	Current	odometer reading:	
	B-Service last performed (Enter 0 if B-Service is performed for f		
	Difference	in mi/km:	
Determin	ne "Additional work" neede	Difference < 14,000 mi 22,000 km	Difference ≥ 14,000 mi 22 000 km B-Service
check if ar		/96,000 km or 4 years	3,100,11
at approx.	every:	L	every: 2 years
	60,000 mi	/96,000 km or 5 years	3 years
			Spark plugs
Determing of the discretion of	an "A-Service" should be perfor	rvice" is less (<) than 14,000 m rmed. rvice" is greater (≥) than 14,00	iles/22 000 km (as determined from Service Booklet or deal 00 miles/22 000 km (as determined from Service Booklet or

Additional flat rates apply for procedures marked with FAP.

completed	ΝE	A-Service		O B-Service	Not O.K.	
	V	Vehicle passenger compartment	V	V	V	
		venice passenger comparement				
		Function check				
		Warning/indicator lamps, illumination and interior lighting	\boxtimes	\otimes		
		Throttle cable: operate accelerator cable slowly by foot through full range of travel. i Observe smoothness of operation If roughness is detected, replace throttle cable.		⊗		AP30.10-P-3022GH
		Windshield wipers, rear window wiper, windshield/rear window washer system	\boxtimes	\otimes		AP82.35-P-8252GH
		Headlamp cleaning system	\times	\otimes		
		Replace dust filter		\otimes		AP83.00-P-8381GH
		Check seat belts for damage and proper function		\otimes		AP91.40-P-9150GH
		Reset FSS counter in instrument cluster	\boxtimes	\otimes		
		Wheels, brakes			3000	
		Check front brake pads for lining thickness (remove 1 front wheel at "A" service)	\boxtimes			AP42.10-P-4251GH
		Check brake pad thickness (front and rear)		\otimes		AP42.10-P-4251GH
		Check condition/thickness of brake discs front/rear		\otimes		AP42.10-P-4251GH
		Check tires for damage and condition	\times	\otimes		AP40.10-P-4051Z
		Measure tread depth, enter in mm:		\otimes		AP40.10-P-4051Z
		LF RF LR RR				
		outside				
		center				
		inside				
		Correct tire inflation pressure including spare	\boxtimes	\otimes		
		Vehicle underbody				
completed	ΙX	A-Service		O B-Service	Not O.K.	
	–		\downarrow	↓	<u> </u>	
	П	Visual inspection for leaks: Leakage - Major components Chafe marks, line routing, damaged components. In the event of leakage, determine cause and perform repair via separate work order.		⊗		AP00.20-P-0053GH

FAP		4 years: Replace air cleaner filter element				
complete	ed ⊠ ↓	Perform: At approx. every 60,000 mi/96,000 km or	yes ↓	Not O.	K. ↓	
-	. —	Additional Work				
		Check catch, safety catch and hinges of engine hood for proper operation. Replace components with even the slightest malfunction.	\boxtimes	⊗ [AP88.40-P-8821GH
		Lubricate joints on throttle control, check operation and condition		⊗ [AP30.10-P-3022GH
		Check condition of poly-V-belt		\otimes		AP13.22-P-1351GH
		Windshield washer	\boxtimes	⊗ [AP82.35-P-8210GH
		Additionally, check battery condition using "Midtronics MCR 717" Tester	\boxtimes	⊗ [AP54.10-U-5453A
		If so equipped: Battery, wet cell Check battery acid level, replenish	\boxtimes	⊗ [AP54.10-P-5410A
		Brake system	\boxtimes	⊗ [AP42.10-P-4210Z
		Power steering		⊗ [AP46.00-P-4611BB
		Check and correct fluid level				
		Engine oil and filter change	\boxtimes	⊗ [AP18.00-P-0101GH
		Visually inspect the lower power steering hose connection at the radiator	\boxtimes	If found to be leaking, repla lower power steering hose.	ce	AP46.25-U-4645GH
		Visual inspection for leaks: Leakage - Major components Chafe marks, line routing, damaged components. In the event of leakage, determine cause and perform repair via separate work order.		⊗ [AP00.20-P-0053GH
		Engine compartment			_	
		components and rubber boots				AP46.00-P-4653GH
		rubber boots Check condition of steering's mechanical		× .	_	
		and rubber boots Check condition of rear axle ball joints and		⊗	7	AP35.20-P-3555GH
		Check condition of front axle ball joints		lower power steering hose.		AP33.20-P-3353GH
		Visually inspect the lower power steering hose connection at the radiator		i If found to be leaking, repla	ce	AP46.25-U-4645GH

	At approx. every 60,000 mi/96,000 km or 5 years:		
₩AP	Replace fuel filter		AP47.20-P-0780GH
	Every 2 years:		
₩ AP	Replace brake fluid		AP42.00-P-4280GH
₩ AP	Check body for paint damage by Service Advisor		AP98.00-P-9850BA
⊯ AP	Check chassis and supporting body parts for damage and corrosion by Service Advisor		AP00.20-P-0090GH
	Every 5 years:		
₩AP	Sliding/pop-up roof: clean and grease sliding rails and sliders		AP77.20-P-7730GH
	At approx. every 150,000 mi/250,000 km or 15 years		
₩AP	Replace coolant		AP20.00-P-2080GH
	Replace spark plugs		
⊯ AP	At approx. every 100,000 mi/160,000 km or 5 years: As of M.Y. 2000		AP15.10-P-1580GH