

MODEL 164

Light Truck Model Year 2006
USA

Model 164



Customer: _____

Repair order number: _____

First visit	at 1,000 - 3,000 miles	Performed	YES <input type="checkbox"/>	NO <input type="checkbox"/>
Tire Rotation	Performed in accordance with the tire manufacturer's recommended intervals	Tires rotated	YES <input type="checkbox"/>	NO <input type="checkbox"/>
Tire Inspection	Inspect tires for damage and correct tire inflation pressure	Tires inspected	YES <input type="checkbox"/>	NO <input type="checkbox"/>

Current mileage reading: _____

Oil grade/viscosity: _____

Additional notes: _____




Service work to be performed as advised by service advisor: _____




Completion date: _____








Confirm work has been performed by signing below: _____



US Service 4 through US Service 20 apply to "Additional work" items only.
 Vehicle determines need for US Service 3 (Engine oil and filter change) as well as US Service 1 or US Service 2
 Perform service necessary as indicated in display of instrument cluster only.
 Perform each service as described.

US Service 1	US Service 2	first at 13,000 mi or 1 year; after first every 26,000 mi or 2 years	first at 26,000 mi or 2 years; after first every 26,000 mi or 2 years	Not OK																				
↓	↓			↓																				
	Interior																							
<input type="checkbox"/>	<input type="radio"/>	Reset service indicator in instrument cluster		AP00.20-P-0042GZ																				
Function test																								
<input type="checkbox"/>	<input type="radio"/>	Check battery condition using "Midtronics MCR 717" Tester	<input type="checkbox"/>	AP54.10-U-5453A																				
	<input type="radio"/>	Check parking brake (function test only)	<input type="checkbox"/>	AP42.00-P-4290GZ																				
<input type="checkbox"/>	<input type="radio"/>	Horn, warning/indicator lamps, illumination and interior lighting	<input type="checkbox"/>																					
<input type="checkbox"/>	<input type="radio"/>	Windshield washer system	<input type="checkbox"/>	AP82.30-P-8252GZ																				
<input type="checkbox"/>	<input type="radio"/>	Headlamp cleaning system	<input type="checkbox"/>																					
	<input type="radio"/>	Check seat belts and buckles for signs of external damage and proper function	<input type="checkbox"/>	AP91.40-P-9150GZ																				
	Wheels, brakes																							
<input type="checkbox"/>	<input type="radio"/>	Inspect tires for damage and splits, measure tread depth, record in mm:		<input type="checkbox"/>																				
		<table border="0" style="margin-left: auto; margin-right: auto;"> <tr> <td></td> <td style="text-align: center;">LF</td> <td style="text-align: center;">RF</td> <td style="text-align: center;">LR</td> <td style="text-align: center;">RR</td> </tr> <tr> <td style="text-align: right;">outside</td> <td style="text-align: center;">_____</td> <td style="text-align: center;">_____</td> <td style="text-align: center;">_____</td> <td style="text-align: center;">_____</td> </tr> <tr> <td style="text-align: right;">center</td> <td style="text-align: center;">_____</td> <td style="text-align: center;">_____</td> <td style="text-align: center;">_____</td> <td style="text-align: center;">_____</td> </tr> <tr> <td style="text-align: right;">inside</td> <td style="text-align: center;">_____</td> <td style="text-align: center;">_____</td> <td style="text-align: center;">_____</td> <td style="text-align: center;">_____</td> </tr> </table>		LF	RF	LR	RR	outside	_____	_____	_____	_____	center	_____	_____	_____	_____	inside	_____	_____	_____	_____		
	LF	RF	LR	RR																				
outside	_____	_____	_____	_____																				
center	_____	_____	_____	_____																				
inside	_____	_____	_____	_____																				
	<input type="radio"/>	Remove and fit wheels		AP40.10-P-4050Z																				
<input type="checkbox"/>	<input type="radio"/>	Check front brake pads for lining thickness, remove 1 front wheel	<input type="checkbox"/>	AP42.10-P-4251GZ																				
	<input type="radio"/>	Check front/rear brake pads for lining thickness	<input type="checkbox"/>	AP42.10-P-4251GZ																				
	<input type="radio"/>	Check condition/thickness of front/rear brake discs	<input type="checkbox"/>	AP42.10-P-4251GZ																				
<input type="checkbox"/>	<input type="radio"/>	Correct tire inflation pressure	<input type="checkbox"/>																					
	Underside of vehicle																							
	<input type="radio"/>	Leakage - Major components Check for chafe marks, line routing, damaged components i In the event of leakage, determine cause and perform repair via separate work order	<input type="checkbox"/>	AP00.20-P-0053GZ																				
	<input type="radio"/>	Inspect condition of flexible disks	<input type="checkbox"/>																					
	<input type="radio"/>	Check front axle ball joints for play, check rubber boots	<input type="checkbox"/>	AP33.20-P-3353GZ																				
	<input type="radio"/>	Check rear axle ball joints for play, check rubber boots	<input type="checkbox"/>	AP35.20-P-3555GZ																				
	<input type="radio"/>	Inspect play of tie rod and and drag link joints, inspect rubber boots	<input type="checkbox"/>	AP46.00-P-4653GZ																				

Service 1	2		Not OK
↓	↓		↓
	Vehicle front/rear		
<input type="checkbox"/>	<input type="radio"/> Check wiper blade condition		<input type="checkbox"/> AP82.30-P-8253G
	<input type="radio"/> Check and correct headlamp setting		<input type="checkbox"/> AP82.10-P-8260GZ
	Trunk		
<input type="checkbox"/>	<input type="radio"/> Check spare tire inflation pressure		<input type="checkbox"/>
	Engine compartment		
	<input type="radio"/> Leakage - Major components Check for chafe marks, line routing, damaged components i In the event of leakage, determine cause and perform repair via separate work order		<input type="checkbox"/> AP00.20-P-0053GZ
<input type="checkbox"/>	<input type="radio"/> Check catch, safety catch and hinges on engine hood for proper operation.		<input type="checkbox"/> AP88.40-P-8851GZ
	<input type="radio"/> Check condition of poly-V-belt		<input type="checkbox"/>
	Check fluid level, correct as required i If there is a loss of fluid, determine cause and perform repair via separate work order		
<input type="checkbox"/>	<input type="radio"/> Brake system		<input type="checkbox"/> AP42.10-P-4210GZ
	<input type="radio"/> Power steering	Type 164.175	<input type="checkbox"/> AP46.00-P-4611GZ
		Type 164.186	<input type="checkbox"/>
<input type="checkbox"/>	<input type="radio"/> Windshield washer system (incl. summer/winter cleanser)		AP82.35-P-8210GZ
Additional Work			
Completed <input checked="" type="checkbox"/>			Not OK
	↓		↓
US Service 3	every 13,000 mi or 1 year:		
	Engine compartment		
<input type="checkbox"/>	Engine - oil and filter change	Engine 113:	AP18.00-P-0101GZ
		Engine 272:	AP18.00-P-0101GZC
US Service 4	every 2 years:		
<input type="checkbox"/>	Check bodywork for paint work damage by service advisor		<input type="checkbox"/> AP98.00-P-9850GZ
	Underside of vehicle		
<input type="checkbox"/>	Chassis and load-bearing body components: Check for damage and corrosion by service advisor		<input type="checkbox"/> AP00.20-P-0090GZ
	Engine compartment		
<input type="checkbox"/>	Replace brake fluid		AP42.00-P-4280GZ

Completed <input checked="" type="checkbox"/>				Not OK
↓				↓
US Service 5	every 26,000 mi or 2 years: Passenger compartment			
<input type="checkbox"/>	Replace combination filter			AP83.00-P-8384GZ
US Service 6 and 7	not applicable			
US Service 8	every 52,000 mi or 4 years: Engine compartment			
<input type="checkbox"/>	Replace engine air-cleaner insert	Engine 113:	AP09.10-P-0980GZ	
		Engine 272:	AP09.10-P-0980GZC	
US Service 9 and 10	not applicable			
US Service 11	every 65,000 mi or 5 years: Engine compartment			
<input type="checkbox"/>	Replace fuel filter	Engine 113:	AP47.20-P-0780GZ	
		Engine 272:	AP47.20-P-0780GZC	
US Service 12 Engine 113	every 91,000 mi or 5 years: Engine compartment			
<input type="checkbox"/>	Replace spark plugs			AP15.10-P-1580GZ
US Service 12 Engine 272	every 78,000 mi or 5 years: Engine compartment			
<input type="checkbox"/>	Replace spark plugs			AP15.10-P-1580GZC
US Service 13	every 143,000 mi or 15 years: Engine compartment			
<input type="checkbox"/>	Replace coolant	Engine 113:	AP20.00-P-2080GZ	
		Engine 272:	AP20.00-P-2080GZC	
US Service 14 - 19	not applicable			
US Service 20	once at 39,000 mi: Underside of vehicle			
<input type="checkbox"/>	Automatic transmission - oil and filter change			AP27.00-P-2702W
Completed <input checked="" type="checkbox"/>	Perform:	Yes	Not OK	
↓		↓	↓	
Vehicle over 143,000 mi:				
Check if all fluid levels and changes are up-dated				
 AP	<input type="checkbox"/> Transmission	<input type="checkbox"/>	<input type="checkbox"/>	
 AP	<input type="checkbox"/> Rear axle	<input type="checkbox"/>	<input type="checkbox"/>	
 AP	<input type="checkbox"/> Front axle	<input type="checkbox"/>	<input type="checkbox"/>	
 AP	<input type="checkbox"/> Transfer case	<input type="checkbox"/>	<input type="checkbox"/>	
Check if air, fuel, ventilation filters are up-dated				
 AP	<input type="checkbox"/> Engine air filter	<input type="checkbox"/>	<input type="checkbox"/>	
 AP	<input type="checkbox"/> Fuel filter	<input type="checkbox"/>	<input type="checkbox"/>	
 AP	<input type="checkbox"/> Combination filter	<input type="checkbox"/>	<input type="checkbox"/>	

Completed <input checked="" type="checkbox"/>	Perform:	Yes	Not OK
	↓	↓	↓
Check integrity of engine, mechanical components			
AP	<input type="checkbox"/> Perform compression test (hot and cold) Refer to BE01.00-Z-9999AZ	<input type="checkbox"/>	<input type="checkbox"/>
AP	<input type="checkbox"/> Perform leak down test (hot and cold)	<input type="checkbox"/>	<input type="checkbox"/> AP00.20-P-0053GZ
AP	<input type="checkbox"/> Check spark plugs	<input type="checkbox"/>	<input type="checkbox"/>
AP	<input type="checkbox"/> Exhaust system hangers and leaks	<input type="checkbox"/>	<input type="checkbox"/>
Check damaged / worn drivetrain parts			
AP	<input type="checkbox"/> Front wheel bearing play	<input type="checkbox"/>	<input type="checkbox"/>
AP	<input type="checkbox"/> Rear wheel bearing play	<input type="checkbox"/>	<input type="checkbox"/>
AP	<input type="checkbox"/> Axles joint play	<input type="checkbox"/>	<input type="checkbox"/>
AP	<input type="checkbox"/> Flexible discs	<input type="checkbox"/>	<input type="checkbox"/>
AP	<input type="checkbox"/> Tie rod and drag link joints	<input type="checkbox"/>	<input type="checkbox"/>